



# TRIM ASSEMBLY INSTRUCTIONS - PASSAGE FUNCTION

TO HAND RHR, REFER TO REVERSE SIDE

- 1 REMOVE SCREW SECURING BACKPLATE TO HOUSING.
- 2 INSTALL STUDS ON BACK PLATE WITH CENTER STUDS INSTALLED CLOSEST TO HANDLE SIDE
- 3 INSTALL TAILPIECE ASSEMBLY INTO CLUTCH PLATE. INSTALL INTO LEVER CAM.  
NOTE: BLACK LINES MUST MATCH UP ON ASSEMBLY. SEE INSET
- 4 INSTALL BACK PLATE WITH 5 EA. 8-32 MS.

